

Eclipse Zone 8 PS

Zone expander with mains power supply


Description

Eclipse Zone 8 PS is an expander with mains power supply for adding of 8 additional programmable zone inputs to ECLIPSE 32 system configuration. The added zone inputs are fully programmable from the control panel.

The expander module can be mounted in a big universal small plastic box.

Technical Specifications

| | |
|---|-------------------|
| Power Supply from the control panel . . . | 9-18VDC |
| Mains Transformer | 17V/17VAC |
| Consumption | Max. 100mA@12VDC |
| Zone inputs | 8 |
| PGM output | 1, 100mA, OC type |
| Indication type | LED |
| Operation temperature | -20 ÷ +50°C |



Functional Specifications

- Connection directly to the system bus;
- 8 additional zone inputs with freely programmable parameters;
- Additional terminal +/- AUX for power supply for detectors with consumption up to 0.75A;
- Additional +PGM output for power supply of auxiliary devices with consumption up to 0.75A;
- Additional PGM output, 100mA, OC type (open collector)
- Own undependable power supply.

Packing Information

- **Master box** - 45 units Zone 8, dimensions 496 x 305 x 206 mm

Compatible Product Range

- **Eclipse 32** - Alarm Control Panel

Информация за контакт